



GYMNASTICS SHOES SIZE CHART (INCHES)

SIZE CHART IN INCHES								
	C8	C9	C10	C11	C12	C13	C1	C2
Bottom Length	6.02 in	6.36 in	6.69 in	7.02 in	7.36 in	7.69 in	8.02 in	8.36 in
	A3	A4	A5	A6	A7	A8	A9	A10
Bottom Length	7.87 in	8.21 in	8.54 in	8.87 in	9.21 in	9.54 in	9.87 in	10.21 in
	A11	A12	A13	A14				
Bottom Length	10.54 in	10.87 in	11.20 in	11.54 in				